



BIG FOOT

Large Diameter Foot Attachment

Part No. BF-1



Big Foot Installation:

1. Loosen the hex screw on the Big Foot attachment
2. Slide the Big Foot attachment onto the lower barrel of the gauge
3. Position the Big Foot attachment so that the ½" gauge foot protrudes approximately .002 - .003" past the Big Foot attachment (the Big Foot should be almost flush with the gauge foot)
4. Tighten the hex screw on the Big Foot attachment

Note: Increasing foot diameter can affect durometer readings.

If you have any questions or comments regarding the use of this or any Rex product, please call 847-465-9009.

For more information visit our Web Site at durometer.com



REX GAUGE COMPANY LLC

847/465-9009

800/927-3982