



# DIN FOOT

## ASTM TYPE R, ISO and DIN FOOT

### 18mm Diameter Foot Attachment

### Part No. DIN-FA



#### DIN Foot Installation:

1. Loosen the hex screw on the DIN Foot attachment
2. Slide the DIN Foot attachment onto the lower barrel of the gauge
3. Position the DIN Foot attachment so that the 1/2" gauge foot protrudes approximately .002 - .003" past the DIN Foot attachment (the DIN Foot should be almost flush with the gauge foot)
4. Tighten the hex screw on the DIN Foot attachment

*Note: Increasing foot diameter can affect durometer readings.*

If you have any questions or comments regarding the use of this or any Rex product, please call 847-465-9009.

For more information visit our Web Site at [durometer.com](http://durometer.com)



## REX GAUGE COMPANY LLC

**847/465-9009**

**800/927-3982**